

# Patio Awning Mounting Height Chart

C= Measurement from top of mounting space to deck	Projection							Recommended Hand Crank Length (Sizes are Approximate)
	5'-9"	6'-11"	8'-6"	10'-2"	11'-8"	13'-2"	14'-6"	
	E= Measurement from the bottom of the valance to deck							
7'-6" (90")	72"	72"	72"	70"	69"	53"	53"	4'
8'	78"	78"	78"	76"	75"	59"	59"	5'
8'-6"	84"	84"	84"	82"	81"	65"	65"	6'
9'	90"	90"	90"	88"	87"	71"	71"	6'
9'-6"	96"	96"	96"	94"	93"	77"	77"	7'
10'	102"	102"	102"	100"	99"	83"	83"	7'
over 10'								8'


The chart above denotes the approximate clearance with the pitch set in the factory set position

## Measuring & Ordering Guidelines

Determine width of awning (A). This requires a clear span with no obstructions. Be sure light fixtures, down spouts, etc. are not in the way. The awning will require 8" of mounting space (B). A minimum of 7'-6" (90") is required from the deck or patio to the top of the mounting space (C). See chart for more detail.

Select the projection that best fits your needs (D). Awnings are available in over 200 beautiful fabric colors and patterns. Choose the one that best compliments your home. Fasteners for mounting on wood included.

*\*Operation. Facing the house specify the side you want the standard crank handle or motor. Outlet required for motor. If no selection is made, awning will ship with right hand operation.*



## ROOF MOUNT KIT SHOULD BE USED WHEN :

- 1) There is insufficient space to mount the awning (8") or when wall obstructions (ie. downspouts or light fixtures) are in the way.
- 2) More height is desired between the bottom of the awning valance and the deck or patio (E)

To determine the mounting height when a roof mount kit is used: Measure the distance from your deck or patio to the roof line edge or the top of the fascia (F) and add 15". This height will now become the (C) measurement.

Awning cannot be mounted to the fascia.  
(see diagram to the right)

